



If fitting to the P6E 2004 trailer the storage bracket for the electrical socket must be removed and relocated to the chassis as fig 2. Ensure all bolts that have been removed are refitted and tightened fully.



Insert dummy ball when trailer is un-hitched by lifting the hitch handle upwards and coupling in the normal way.



Lower the cover over the hitch handle. Insert lock bolt through both holes of the cover. Fit the recessed cup over end of lock bolt, then turn key a quarter turn to lock and remove key.

We have taken every care in the design and manufacture of this security device and we believe that it is an effective deterrent. However we cannot guarantee that it will resist the efforts of the most determined thief and as such we do not accept any liability for loss or damage caused by theft, vandalism or other illegal activity against property to which this device is fitted.

## **Bulldog Security Products**

Units 1 - 4 Stretton Road, Much Wenlock, Shropshire, TF13 6DH.

Tel: 01952 728171 Fax: 01952 728117

Email [sales@bulldogsecure.com](mailto:sales@bulldogsecure.com) [www.bulldogsecure.com](http://www.bulldogsecure.com)

ML-P6E-1

## **Lock Lubrication.**

**IMPORTANT** - To ensure free movement of the lock, spray lock mechanism & ballbearings with WD40 (or equivalent) minimum every four months.